



Retractor Orientation & Seat Belt Type

OP




1. ON PILLAR WITH FLAT ANCHOR

OP(TRI)




2. ON PILLAR WITH TRIANGULAR ANCHOR

IP




3. IN PILLAR WITH TRIANGULAR ANCHOR

PARCEL SHELF




4. REVERSE WIND ON TOP OF PARCEL SHELF

UNDER PARCEL SHELF



5. REVERSE WIND UNDER PARCEL SHELF

Static Lap



Static Lap Sash

